KØVAX

## **Tolecut** K800 - K3000

THE WORLD CHAMPION IN DRY IMPERFECTION REMOVAL.



IMPERFECTION REMOVAL ✓ Easy to Use
✓ Extremely Fast
✓ Maximum Safety

## **Tolecut** K800 - K3000



**TOLECUT** K800 - K3000 Imperfection Removal

BUFLEX DRY K2000 - K3000 Finishing

K2IN1 Polishing

Imperfections are removed in no time, thanks to Tolecut. **Remove dust nibs** with the pre-cut 1/8 sheets K1500 - K3000 in just a couple of seconds. When it comes to concave and convex parts, use the Tolecut sheets in combination with the Tolecard. For **runners and bigger surface irregularities** the grits K800 & K1200, in combination with the Tolecut Pad, are the first choice. After removing the imperfection we recommend to use Buflex Dry in order to save polish time.



GRIT				*APPLICATION
K800		191-1517	191-1527	X
K1200		191-1516	191-1526	$\mathbb{X}$
K1500	192-1513	191-1513	191-1523	$\mathbb{X}$
K2000	192-1512	191-1512	191-1522	$\mathbb{X}$
K3000	192-1511	191-1511	191-1521	$\mathbb{X}$

\*See other side for meaning application icon.